

PASSPORT SM
PREMIER



**GET PREMIUM
GAS INBOARD
PROTECTION.**
FOR TRUE PEACE OF MIND.

Passport Premier offers comprehensive, long-term engine package protection for your boat. Even entire engine assemblies are replaced if necessary. So you can enjoy your time on the water, knowing you are covered against costly repairs for years to come.

**PASSPORT PREMIER LETS YOU
HEAD OUT WITH CONFIDENCE**

- *Long-term coverage on over 160 major engine parts*
- *Covers overheating, even detonation, lots more*
- *Repair reimbursement includes parts and labor*
- *Locking in now offers assurance against inflation*
- *Protection cost can be rolled into your boat financing*
- *All benefits are transferable for higher resale value*

With expert service at any manufacturer authorized facility nationwide, it's coverage you can truly count on.

COMPREHENSIVE EXTENDED PROTECTION BENEFITS

**Non-Defective Engine
Breakdown**

Engine Sensor Failures
Carbonized Rings
Thermostat Failures
Heat Collapses Rings
Overheating*
Scored Pistons
Preignition

Scored Cylinders
Detonation
Heat Cracked Heads
Burnt Valves
Warped Heads
Bent Valves
Heat Cracked Block
Tuliped Valves

Claim Payment Benefits

Lubricants Hoses
Coolants Engine Tuning
Belts Taxes
Spark Plugs Shop Supplies
Clamps Haul Out
Filters

Service Assist

On-water towing
Hoist/lift-out
Haul Out
Dockside repair call
Pick Up/Delivery
Lake Test
Sea Trial

* Any overheating conditions created by raw water pump and/or impeller failures or those that do not result in a Mechanical Breakdown are not eligible for Coverage under this program.

GAS INBOARD ENGINE PACKAGE PROTECTION

Controls: All parts contained within the manual/electronic single or dual shift controls, neutral safety switch, shift switch, lever, control cables, micro switches, potentiometer, control panel, wiring harness, shift actuator, electronic throttle control assembly

Cooling System: Engine circulating pump, heat exchangers, seals, gaskets

Electrical: Alternator, voltage regulator, electronic ignition module, ignition coil, starter, starter solenoid, starter drive, electric choke, electric choke solenoid, engine wiring harness, ignition switch, oil pressure switch, all engine electrical sensors to include distributor ignition sensor, crank position sensor, cam position sensor, coolant temperature sensor ("CTS")

Engine: Crankshaft, main bearings, main bearing bolts, connecting rods, connecting rod bearings, connecting rod bolts, camshaft, camshaft bearings, pistons, piston rings, wrist pins, push rods, lifters, intake valves, exhaust valves, valve seats, valve springs, valve guides, valve spring retainers, valve cover gaskets, timing gears, timing chain, timing belt, timing cover gasket, oil pump, oil filter housing, flywheel, harmonic balancer, thermostat, thermostat housing, thermostat housing gaskets, engine mounts, distributor, head gasket(s), rocker arms, rocker cover, rocker cover gaskets, timing gear cover, timing gear cover gasket, timing cover seal, front main seals, rear main seals, all engine senders/sensors, seals, gaskets

Fuel System: Fuel injectors, injector rails, pressure regulator, low pressure pump, high pressure pump, wiring harness, flame arrestor, fuel cooler, vapor separator ("VST"), idle air control ("IAC") valve, engine-mounted electronic control unit ("ECU") module, all fuel system sensors to include manifold absolute pressure ("MAP") sensor, throttle position sensor ("TPS"), manifold air temperature ("MAT") sensor

Power Trim: Power trim motor/pump, power trim cylinders, cylinder rams, mounts and pivots, trim solenoids, wiring harness, master switches, sender/limit switches, reverse lock valve, power trim reservoir and cap assembly, seals, gaskets

Steering: Steering control helm assembly, control rack and yoke assembly, power steering pump, power steering pump pulley, hydraulic steering pump, hydraulic steering cylinder, steering cable, power steering oil cooler

Sterndrive Control System: Power steering pump, power steering cooler, thrust vector module ("TVM"), TVM cylinder, joystick and associated wiring harness, CCM module, IMU compass

Sterndrive Shaft Housing: Upper drive gear set, clutch dogs and cones, spring kit, shift cams, shims, bearings, bearing carriers, upper drive shaft, spanner cover nut

Sterndrive Intermediate Housing: Intermediate drive shaft, universal joints, u-joint bellows, gimbal bearings, center yoke, drive yoke, steering yoke, gimbal ring, bell housing, gimbal ring bushings, hinge pins and screws, engine coupler, oil reservoir bottle and cap, reservoir level switch assembly, intermediate shift cable, shift cable bellows

Sterndrive Lower Unit: Forward, reverse and pinion gears, clutch dog, dog pin, cam follower, prop shafts, drive shaft, shift shaft, shims, bearings, bearing carriers, pinion nut, pinion nut washer

Transmission: Transmission mounts, clutch plates, clutch drums, thrust plates, planetary gears, shift bands, reduction gears, bearings, shafts, bearing carriers, hydraulic pump, hydraulic pistons, valve body, drive plate, temperature switches, neutral safety switch, control valves, transmission oil cooler, shift pressure transducer, seals, gaskets


V-drive: Bearings, thrust bearings, bevel gears, shafts, shims, bearing carriers, drive plate, friction clutch plates, steel clutch plates, pressure plates, clutch drums, springs, snap rings, control valve, regulator valve, hydraulic pump, temperature switches, neutral safety switch, sealing rings, ring gear, v-drive oil cooler, shift pressure transducer, seals, gaskets

Complete Assemblies: Engine block, cylinder head(s), cylinder barrels/sleeves, intake manifold, transmission case, v-drive case, pod drive intermediate housing will be eligible for reimbursement if damaged beyond repair by the failure of a covered component listed above (unless Optional Major Castings/Housings Upgrade is purchased – see your dealer for details).

The information provided in this document is intended to provide only a brief description of the benefits of the Passport Premier Extended Marine Protection. The extended service contract also has exclusions and limitations that apply to the benefits discussed in this document. For complete details as provided in the Agreement booklet (including "What is not Covered") and for costs, please see your dealer representative.

Administrator: Brunswick Product Protection Corporation, Brunswick Product Protection Corp. of Florida, 26125 N Riverwoods Blvd, Suite 500, Mettawa, IL 60045, Phone: 800.950.3808, Fax: 866.404.5831, Email: admin@boatwarranty.com. Obligor: Consumer Program Administrators, Inc., in CA – Motor Warranty Services of North America, CA license #0E40891; in FL, LA and OK – Automotive Warranty Services of Florida, Inc., FL license #60023, OK license #861338; in AR and WA – National Product Care Company; all located at 175 West Jackson Blvd., Chicago, IL 60604, Phone – 800.752.6265

AVOID COSTLY REPAIRS



BTKASS2024GIUS

Average covered original equipment manufacturer (OEM) repair and/or replacement cost examples (retail parts, average labor rate, OEM flat rate for repair times, Service Assist and Claim Payment Benefits) on Mercury MerCruiser 8.2 L 380 HP inboard engine. This document is for general information. Coverage subject to change and includes exclusions. This is not your contract. A complete statement of coverage, specific terms, conditions, benefits and limitations is provided in the provisions of the Passport Premier Agreement Booklet.